



Component repair instructions

<i>Description</i>	<i>Nozzle and holder assembly (2-spring)</i>
<i>RB key</i>	<i>0 432 193 703</i>
<i>Type code</i>	<i>DHK</i>

NOTES ON REPAIR AND TESTING OF 2-SPRING NOZZLE-HOLDER ASSEMBLY

*Nozzle tester EFEP 60H (0681200502)
is no longer suitable for checking and
adjusting nozzle-holder assemblies on
account of:*

- Measurement accuracy*
- Dead space*
- Pressure gauge quality class*

*Warranty examinations with EFEP 60H are
not permitted and result in rejection
of warranty claims.*

